

PER TRIP DOLLAR VALUE BASED DEBITING

How It Works

Any Entrance or any Exit location may be specified as a Debit Reader. Those readers respond normally to card access requests for all cardholders except those cards subject to "Per Trip Debiting". A card subject to Per Trip Debiting must have a sufficient dollar value in their account to gain entry (or exit).

You may specify a different "Per Trip Rate" for each cardholder if you wish, or you may set a default value for all cardholders, and then make exceptions for specific cardholders.

When you add more value to a cardholder's account, the number of remaining trips is automatically adjusted to reflect the added dollar amount.

Command Modules may be ordered so as to pulse the aux relay when a cardholder's account needs replenishing. The relay may be used to sound a sonalert, or turn on a message board.