


Models 4100-SR Proximity Readers


General

The Model 4185-PSR is the standard range indoor or outdoor proximity reader. The prox read head may be mounted against a metal surface, but cannot be surrounded by metal such as when recessed into a metal parking housing.



Self-Contained Housing

An optional parking housing is available which is equipped with a hard rubber



spacer so that the prox head is not surrounded by metal. With this housing, the face plate must be locked into place, and then the reader is fastened to the face plate with provided screws. An adhesive label is provided to hide the screws.

READER TO MODULE WIRING

