


4120/4122 Command Module



The 4120 is a single reader Module, and the 4122 supports two readers. Several mode combinations are available through D.I.P. switch settings. See the explanation of these settings on the reverse side.

Toye Corporation

P.O. Box 3997 Chatsworth, CA 91313-3997
818-882-4000 Fax 818-882-5325 Web: www.toyecorp.com

