

TOYEE CORPORATION

TOYEE

ACCESS CONTROL SYSTEMS

P.O. Box 3997, Chatsworth, CA 91313-3997, Phone (818)-882-4000, Fax (818)-882-5325, www.toyecorp.com

PIN Scramble Program Instructions

NOTE: The Pin.exe program must be used to convert a 5 digit Decimal proximity card number to the corresponding 4 or 5 digit "PIN" number used in the Access Control Software.

This "PIN" number is not user-selectable.

PIN Software Installation Instructions

1. Insert the Software CD into an available CD Drive
2. Type: TCSetup <enter> Wait for the process to complete.
3. Using Windows Explorer, browse to the C:\TC10dir folder.
4. Right-click PIN.exe and create a shortcut. Drag the Shortcut to your desktop.

Using the Pin.exe Conversion Program

1. Double-click the PIN shortcut.
2. At the 1st prompt, tap the letter 'D' (for Decimal systems)
3. At the Scramble Code prompt, type '1234' <Enter>
4. Follow the displayed instructions to display a PIN number that corresponds to the proximity card number entered.
5. Press <Esc> to exit the program and return to Windows.
6. Note: This program is NOT compatible with Windows 7 or 8. It can be used with Windows 7 if you are running Windows XP Mode.

Using the PIN Prox Reader

1. This application is for PIN AND Card. The PIN is only required when a Keypad Command Level is active in the system.
2. To gain access when a Keypad Command Level is active, enter the scrambled PIN plus the # key, and then present the card within 7 seconds. You must use the scrambled PIN derived from each card number using the PIN.exe program.

PinInstr.pdf